




White wire from curly cord  
goes to A+

Wire from pigtail power cord  
goes to L2

Wire from switch assembly  
goes to L1

Black wire from curly cord  
goes to A-

Red wire from potentiometer  
goes to P2

Green wire from potentiometer  
goes to P1

Black wire from potentiometer  
goes to P3