ROTOVAC CARBON BRUSH REPLACEMENT

Tools needed: Flat-Head Screwdriver

- 1) Ensure your Rotovac is disconnected from power source.
- 2) Use a flat-head screwdriver to remove the carbon brush cap P/N: C-020 located both sides of the motor tube, near the top. Turn counter-clockwise until cap comes free.
- Remove carbon brush. Power Wand and DHX P/N: C-018 360 and Wide Track P/N: RP-228
- 4) Insert new carbon brush.
- 5) Use one finger to hold in carbon brush spring while inserting carbon brush cap into the opening. Use a flat head screwdriver to turn the cap counter-clockwise until the threads click into place, then turn clockwise until tight, being careful not to cross-thread.
- 6) Repeat for other side

