



**Wire Locations-**

- L1 Wire from switch that has flag connector (wire is black now but previous versions are white)
  - L2 Black wire from 3 prong power cord
  - A+ White wire from motor gearbox
  - A- Black wire from motor gearbox
  - P1 Green wire from potentiometer (speed control knob)
  - P2 Red wire from potentiometer (speed control knob)
  - P3 Black wire from potentiometer (speed control knob)
- Two remaining wires from switch and 3 prong power cord get crimped together

For potentiometer and 3 prong power cable replacements please reference the previous instructions and wire locations.